SIMPLEX CONTROL AND MESSAGE/ACK EXCHANGE ECE4305 FINAL PROJECT MODULE 6

by

Renato Iida, Le Wang, Rebecca Copper

A Project Report Submitted to Prof. Wyglinski in partial fulfillment of the requirements of ECE 4305

in

Electrical and Computer Engineering

Abstract

Put your abstract here.

Acknowledgements

Contents

List of Figures	v
List of Tables	vi
1 Introduction	1
2 Background	2
2.1 Background subsection	9

List of Figures

List of Tables

Chapter 1

Introduction

This is the introcution to my thesis or dissertation

Chapter 2

Background

Here is some background you'll need to know about my research.

2.1 Background subsection

Just a small section for part of the background of my research. [?]

Bibliography

[1] The Author, Awesome book, WPI Press, 2008.

```
Listing 2.1: FrameObj Source Code
classdef FrameObj
   %FRAMEOBJ has 2 input configuraions; 4 inputs mean you are using the
    %frame requirements to create a FrameObj, 1 input means you are using
    %the bits
        In the first configuration (4 inputs) the first 3 inputs must be
        numbers and it is recommended that the constant properties of
        FrameObj are used to ensure accuracy. The last input depends on the
        frameType.
        -DATAFRAME: the last input must be a string and only the first 234
            characters will be included.
         -ACKFRAME: the last input does not matter but must exist.
        -POLLFRAME
        -REQFRAME
        -TABLEFRAME
       In the second configuration (1 input) the input must be a binary
       nx1 array with a supported frame type in the first byte. To ensure
       that there is no indexing outside the dimensions of the input array
        it is best if all inputs have a size of 1920x1
```

properties (Constant)

%for sndID and rcvID

```
IDBS1 = 100;
   IDUE1 = 101;
   IDUE2 = 102;
   IDUE3 = 203;
   IDBS2 = 200;
   IDALLUE = 000;
   % for frameTypes %these numbers are chosen to resist flips and
   % shifts. It is the most important that frameType is correct as
   % very wrong frames can be dropped based on frameType
   DATAFRAME = 240; %1111 0000
   ACKFRAME = 255; %1111 1111
   POLLFRAME = 202; %1100 1010
   REQFRAME = 83; %0101 0011
   TABLEFRAME = 15; %0000 1111
   INVALID = 0; %0000 0000
   % for classUse
   ENCODE = 1;
   DECODE = 2;
   CHUE1BS1 = 1;
   CHUE2BS1 = 2;
   CHBS1BS2 = 3;
   CHUE3BS2 = 4;
   CRCOK = 1;
   CRCFAIL = 2;
   ACKRECEIVED = 3;
   TIMEOUT = 4;
   MAXDATA = 234; % Probably the only constant that has meaning
   MAXBYTES = 240;
end
properties
```

```
classUse
               %Identifies which configuration we are in
    frameType
                %Identifies the type of frame that is being used
    rcvID
                %The identification number of the destination receiver
                %The identification number of the sender.
    sndID
    dat.a
                %The data field (cuts off after more than 234 bytes)
end
properties (Dependent)
    dataSize
               %Indicates the length of the payload in bytes.
   header
                %The array of the frame header with hCRC8
   hCRC8
               %CRC-8 code verfication of the header field
    dCRC8
                %CRC-8 code verfication of the data field
    frameArray %The frame as an n*1 array
end
methods
    %This function sets the inputs to the property functions below.
    %Those functions define the actual properties, this is where we
    %call those functions.
    function obj = FrameObj(inputType,inputrcvID,inputsndID,inputData)
        % create a FrameObj with 4 inputs from the frame requirements
        if nargin == 4
            obj.classUse = inputType;
            %test if the frame type is valid
            obj.frameType = inputType;
            obj.rcvID = inputrcvID;
            obj.sndID = inputsndID;
            obj.data = inputData;
        %create a FrameObj with 1 array of bits
        elseif nargin == 1
            %Not sure if we need to do this. It might just be a
            %reminder that inputType is not the data that is being used
            %by the class properties in this case.
            bitwise = inputType;
```

```
%size check
    [size_in, \neg] = size(bitwise);
    if (size_in \ge 40)
        % hCRC check
        % needed for the crc calculation
        hDetect = comm.CRCDetector([8 7 6 4 2 0]);
        % detects if there is an error in the CRC of the header
        [\neg, err] = step(hDetect, bitwise(1:5*8,1));
        if (err ==0)
            obj.classUse = bitwise;
            %We are actually converting the array of bits here
            %and then passing the pretty decimal numbers we get
            %to the propertyfunctions.
            obj.frameType = bi2de(bitwise(1:8,1)','left-msb');
            obj.rcvID = bi2de(bitwise(1+8:2*8,1)','left-msb');
            obj.sndID =bi2de(bitwise(1+2*8:3*8,1)','left-msb');
            %Whether there is data or not depends on frameType.
            %The location of data in the frame is dependent on
            %dataSize so we pass the unaltered FrameObj input
            %to obj.data
            obj.data = bitwise;
        else
            % the crc does not match and the header is junk
            obj.frameType = FrameObj.INVALID;
        end
    else
        % the data we recdived is not long enough to check the
        % header crc
        obj.frameType = FrameObj.INVALID ;
    end
else %incorrect number of inputs
    error('That is not a valid number of inputs')
end
```

```
end
%classUse
        %This property enables us to distingush between the two uses of the
        %class FrameObj though the length of the first (or only) input.
        %This is only used by obj.data which takes both string type inputs
        %and arrays of bits and needs to be able to distinguish them
        function obj = set.classUse(obj,inputframeType)
            [array\_or\_vector, \neg] = size(inputframeType);
            if array_or_vector == 1
                obj.classUse = FrameObj.ENCODE;
            else
                obj.classUse = FrameObj.DECODE;
            end
        end
%frameType
        function obj = set.frameType(obj,inputframeType)
            %Using the switch statement in this way ensures that a
            %supported data type is used
            switch inputframeType
                case FrameObj.DATAFRAME %DATA
                    obj.frameType = uint8(inputframeType);
                case FrameObj.ACKFRAME %ACK
                    obj.frameType = uint8(inputframeType);
                case FrameObj.POLLFRAME %POLL
                    obj.frameType = uint8(inputframeType);
                case FrameObj.REQFRAME %REQ
                    obj.frameType = uint8(inputframeType);
                case FrameObj.INVALID
                                       %INVALID
                    obj.frameType = uint8(inputframeType);
                otherwise % also INVALID
                    obj.frameType = uint8(FrameObj.INVALID);
            end
        end
%rcvID
```

```
function obj = set.rcvID(obj,inputrcvID)
            obj.rcvID = uint8(inputrcvID);
        end
%sndID
        function obj = set.sndID(obj,inputsndID)
            obj.sndID = uint8(inputsndID);
        end
%data
        %frameType dependent
        %classUse dependent
        %Data actually refers to the data and the CRC8 number in an n \star 1
        %binary array
        function obj = set.data(obj,datainput)
            %These variables mean we can vary the size of MAXBYTES or the
            %header without and data will still be functional.
            header_bits = (FrameObj.MAXBYTES-(FrameObj.MAXDATA+1)) *8;
            max_data_bits = FrameObj.MAXDATA*8;
            switch obj.frameType
                case FrameObj.DATAFRAME %DATA
                    if obj.classUse == FrameObj.ENCODE;
                        %This converts the datainput into an array of bits
                        temp_bin = reshape(dec2bin(datainput,8)',1,[]);
                        %Define the length of temp_data for speed
                        % the length of temp_data is limited by MAXBYTES
                        if size(temp_bin,2)≥max_data_bits
                            temp_data = zeros(1, max_data_bits);
                        else
                            temp_data = zeros(1, size(temp_bin, 2));
                        end
                        for j=1:size(temp_data,2)
                            temp_data(1,j) = str2num(temp_bin(1,j));
                        end
```

```
crcGen = comm.CRCGenerator([8 7 6 4 2 0]);
        %Calculates the CRC and adds it to the end of data
        obj.data = step(crcGen, temp_data');
    elseif obj.classUse == FrameObj.DECODE;
        data_bits = size(datainput, 1)-header_bits -8;
        %This seperates the data from the rest of the array
        %using dataSize.
        %First seperate dataSize then convert to decimal
        %Cast to double and convert from bytes to bits
        Temp = bi2de(datainput(1+3*8:4*8,1)','left-msb');
        ds = double(Temp*8);
        %This allows FrameObj to not exceed the dimensions
        %of inputdata in case the dataSize was corrupted to
        %be or larger than the length of the input array
        %and passed the hCRC.
        if ds \ge data\_bits
            ds = data_bits
        end
        % or larger than MAXDATA
        if ds > max_data_bits
           ds = max_data_bits
        end
        %Seperate data using the start of the data and the
        bits = datainput(header_bits+1:header_bits+ds+8,1);
        %cast to double
        obj.data = double(bits);
    end
case FrameObj.ACKFRAME %ACK
    obj.data = ''; %could be anything
    %if there is no data you should not try to access tha
    %ACK data but data is always assesed regardless of the
```

```
%frameType
                case FrameObj.POLLFRAME %POLL
                    obj.data = bi2de(datainput); %work on this
                        %is there anything we don't want converted here?
                        %unsure
                case FrameObj.REQFRAME %REQ
                    obj.data = bi2de(); %work on this.
                %Do we need this? Currently no data to be passed besides
                %recID and sendID.
                case FrameObj.INVALID %INVALID
                    obj.data = ''; %could be anything
                    %if there is no valid frameType you should not try to
                    %access tha data but data is always assesed regardless
                    %of the frameType
                otherwise
                    error('Not a supported frame type for data')
                    % If this error occurs while using a legitimate frame
                    % type please add an addiional case statement for that
                    % frame type.
                    % if there is no data for this frame type copy ACKFRAME
                    % if there is string data copy DATAFRAME
                    % A diferent type of data may require a different case
            end
        end
%dataSize
        % frameType dependent
        % returns 0 if ACK
        function value = get.dataSize(obj)
            switch obj.frameType
                case FrameObj.DATAFRAME %DATA
                    %Convert from bits to bytes and subtract 1 to account
                    %for the CRC
                    value = (length(obj.data)/8)-1;
                case FrameObj.ACKFRAME %ACK
                    value = 0;
```

```
%the ACKFRAME has no data but it must have a dataSize
                otherwise
                    error('Not a supported frame type for dataSize')
                    % If this error occurs while using a legitimate frame
                    % type please add an addiional case statement for that
                    % frame type.
                    % If there is no data for this frame type copy ACKFRAME
                    % If there is data copy DATAFRAME
                    \mbox{\ensuremath{\upsigma}} A different type of data may require a different case
            end
        end
%dCRC8
        %frameType dependent
        function value = get.dCRC8(obj)
            switch obj.frameType
                case FrameObj.DATAFRAME %DATA
                    %The last byte of obj.data is the CRC. It is seperated
                    %from the data here
                    [m, \neg] = size(obj.data);
                    value =zeros(8,1);
                                            %Define value for speed
                    for j=1:8
                        value(j,1) = obj.data(m-8+j,1);
                    end
                case FrameObj.ACKFRAME %ACK
                    error('This is an ACK, it has no data therefor no CRC')
                    %If there is no data there should be no check
                otherwise
                    error('Not a supported frame type for CRC8')
                    % If this error occurs while using a legitimate frame
                    % type please add an addiional case statement for that
                    % frame type.
                    % If there is no data for this frame type copy ACKFRAME
                    % If there is data copy DATAFRAME
            end
```

```
end
%header
       %all frametypes have the same length and components
       %frametype, sndID, rcvID, dataSize, hCRC8
       function value = get.header(obj)
           % Each part of the header is converted into binary arrays
           type_array = de2bi(obj.frameType, 8, 'left-msb');
           rcvid_array = de2bi(obj.rcvID, 8, 'left-msb');
           sndid_array = de2bi(obj.sndID, 8, 'left-msb');
           size_array = de2bi(obj.dataSize,8,'left-msb');
           temp_header = [type_array rcvid_array sndid_array size_array];
           crcGen = comm.CRCGenerator([8 7 6 4 2 0]);
           %Calculates the CRC and adds it to the end of header
           value = step(crcGen, logical(temp_header'));
       end
%hCRC8
       function value = get.hCRC8(obj)
           % The last byte of obj.header is the hCRC
           [m, \neg] = size(obj.header);
           for j=1:8
               value(j,1) = obj.header(m-8+j,1);
           end
       end
%frameArray
       %frameType dependent
       %ACKFRAME --> frametype, sndID, rcvID, dataSize, hCRC8
       %DATAFRAME--> frametype, sndID, rcvID, dataSize, hCRC8, data, dCRC8
       % If we want to fill the end with zeros that could easily be done
       function value = get.frameArray(obj)
           % for data we combine the data and header in a n*1 binary array
           % the ack is only a header.
```

```
% both header and data have a crc8 included
              switch obj.frameType
                   case obj.DATAFRAME
                        value = [obj.header; obj.data];
                   case obj.ACKFRAME
                        value = [obj.header];
                   otherwise
                        error('Not a supported frame type for frameArray')
                        % If this error occurs while using a legitimate frame
                        % type please add an addiional case statement for that
                        % frame type.
                        \mbox{\ensuremath{\,^\circ}} If there is no data for this frame type copy \mbox{\ensuremath{\,^\circ}} \mbox{\ensuremath{\,^\circ}} \mbox{\ensuremath{\,^\circ}}
                        % If there is data copy DATAFRAME
                        %A different type of frame may require a different case.
              end
         end
    end
end
```